



OPTICA

SHOWER MIXER VALVE KIT

INSTALLATION INSTRUCTIONS

1. Determine the location and height of the shower diverter valve. The valve should be mounted between the studs of the enclosure area.
2. Install a 2x6 blocking between the studs as shown in illustration "A" and "B".
3. Install and connect hot water, cold water and shower supply lines using 1/2"-NPT fittings and 1/2" copper tubing.
4. Secure the valve to the 2x6 blocking with brackets (not provided) as shown in illustrations "A" and "B". Do not remove the plastic protective housing from the valve at this time.
5. A 2-3/4" diameter hole is required through the waterproof drywall and finish material.
6. Remove the plastic protective housing from the valve.
7. Apply a 1/2" bead of caulking behind the face plate. Push it firmly against the finished wall. See illustration "B".

